

Recommended Prohibitions in a Hoot Aerobic System

Inert Materials:

Plastic, Rubber, Scouring Pads, Dental Floss, Cigarette Filters, Bandages, Hair, Mop Strings, Lint, Rags, Cloth and Towels do not degrade in an on-site treatment system. Inert Materials will build up solids, and lead to system malfunction, clogging or increased pump out frequency.

Paper Products:

Disposable Diapers, Paper Towels, Baby Wipes, Facial Tissues, Moist Toilet Paper are not designed to dissolve in an on-site treatment system. Excessive Amounts of toilet tissue will also not decompose. All can lead to system malfunction, back-up or increased pump out frequency.

Food Wastes:

Do not put Animal Fats & Bones, Grease, Coffee Grounds, Citrus & Mellon Rinds, Corn Cobs, Egg Shells, down the sink. Garbage disposal use should limited to waste that cannot be scooped out and thrown in the trash. Spoiled Dairy Products and Yeasts from home Brewery or Baking may cause excessive growth of microbes that do not degrade sewage.

Medicinals:

Do not flush Baby Wipes, Lotioned or Scented Toilet tissue, Female Sanitary Products, Cotton Balls or Swabs, Condoms or expired Medicines/Antibiotics. Septic Tank additives generally do more harm than good. Automatic Disinfection Tablets (blue, clear or otherwise) will kill the organisms needed to consume waste.

Chemicals & Toxins:

Can kill the microbes necessary for Treatment. Paint, Thinner, Solvents, Volatile Substances, Drain Cleaners, Automotive Fluids, Fuels, Pesticides, Herbicides, Fertilizers, Metals, Disinfectants, Sanitizers, Bleach, Mop Water, Excessive use of Household chemicals, and Backwash from Water Softener regeneration.

Laundry Practices:

On-site systems must process the water as it enters the system. Laundry should be spread out over the week, not all run at one time. Excessive use of Detergents, especially those containing bleach, can affect system performance. Liquid detergents are recommended over powders. Fabric Softener sheets are recommended over liquid softeners. Bleach should be used sparingly and at half the rate indicated on the container.

Clear Water Waste:

From A/C Discharge lines, Floor Drains, Gutters, Whole House Water Treatment Systems and Sump Pumps can increase the flow to your treatment system. These flows can at least disrupt, if not destroy your treatment process.